

30' Wide 2-3/8" Arch Dia. 5' Straight Side Gothic Greenhouse Frame Length	96
Arch Spacing	6
Number of Purlin Runs	5
Purlin & Windbrace Gauge	14
Sidewall / Ground Stake Length (7), (8) or (10)	7
Cross Connectors (1) or Pipe Straps (2)	1
Cross Braces, Every Arch (1), Every 2nd Arch (2), Every 3rd Arch (3)	1
Z30A 30' Gothic Arch Half (2-3/8" - 14 ga.)	34
GFA2141 1" No. 14 SS Tek Screws Bags/50 to Fasten Stake to Arch	2
GFA337 3/8" Driver Bit	1
Z30C 5' Arch Coupler for 30' Gothic (2-3/8" - 14 ga.)	17
7' 2-3/8" Swedged Stake, Install 32" below grade for 5' Sidewall	34
8' 2-3/8" Swedged Stake, 44" for 5' Sidewall or 32" for 6' Sidewall	
10' 2-3/8" Swedged Stake, 44" for 7' Sidewall or 32" for 8' Sidewall	
GPS020 2-3/8" Pipe Strap for baseboard	68
GLB025015 1/4" x 1-1/2" Galv. Lag Bolt	136
12' 14 ga Swaged 1.315 Purlin Pipes, Use 2 @ ea. corner for windbrace	48
12' 17 ga Swaged 1.315 Purlin Pipes, Use 2 @ ea. corner for windbrace	
GCC237 2-3/8" Cross Connectors for Purlins except both Sides and Ridge	30
GPS010 1-3/8" Pipe Straps for All Arches & Windbraces, Optional	
GPS010 1-3/8" Pipe Straps for both Side Purlins, Ridge Purlin and Windbrac also use for all purlins at both end arches	75
GFA2121 1" No. 12 SS Tek Screws Bags/100	6
ZGSD XL Ground Stake Driving Bolt 1-3/4x4"	1
GFA331 5/16" Driver Bit	1
Plain 12' 14 ga Crossbrace Half, 1.315 w/one end flattened/punched	15
Swaged 12' 14 ga Crossbrace Half, 1.315 w/one end flattened/punched	15
4' 14 ga. Short Brace 1.315" w/both ends flattened/punched	30
GFA3237 2-3/8" Brace Bands	60
GFA31315 1-3/8" Brace Bands	30
GCB031015 5/16"x1-1/2" Galv. Carriage Bolt	90
GN 031 5/16" Galv. Nut	90
GFA24237 2-3/8" 2x4 End Wall Bracket	18